





## Wireless Remote Control

# RC-80

User Manual



### Overview



### Specifications

#### Power supply

DC 3V (CR2025 Lithium Battery x 1pc)

#### Working current

≤ 7mA

#### Transmitting distance

≤ 80m (in open area)

#### Radio frequency

315MHz or 433.92MHz (± 75KHz)

#### Housing material

ABS plastic

#### Operation Condition

Temperature -10°C ~ +55°C

Relative humidity ≤80% (non-condensing)

#### Dimensions (L x W x H)

58 x 31 x 9.5mm

### Introduction

The remote control enables you to turn the alarm system on and off before entering the home or after exiting. If there is an emergency, press SOS button on the remote control to trigger the panel. RC-80, compact and portable, is designed to fit on a keychain, in a pocket, or in a purse.

### LED Indication

**LED flashes once:** sends the transmitting signal.

**Dim light:** Low battery, please replace the battery immediately.

### Usage

	Arm	Press to arm the alarm panel and all of the accessories. (Away Mode)
	Disarm	Press to disarm the alarm system.
	Stay/ Home Mode	Press to arm all sensors except the ones in zone A or Home Mode Zone, sensors in zone A or Home Mode Zone will not activate an alarm.
	Panic	Press to activate a panic alarm and the control panel auto-dials the pre-set phone numbers immediately.
	Mute Arm	Press to arm the system in mute.
	Mute Disarm	Press to disarm the system in mute.

# CHUANGO®

产品型号	RC-80	部件名称	说明书
设计	林寿	材料	80克书写纸
印刷尺寸	285X210mm	成品尺寸	95X70mm
工艺	折页	版本	Ver: RC-80-UM-EN-V1.0

**注:**  
双色、单面印刷  
保持产品名称在最上面