

DIGITAL PC SCOPE

Digital storage oscilloscoop, using a computer and its monitor to display waveforms. All standard oscilloscope functions are available in the Windows program supplied.





Features :

- I channel
- ☑ input impedance: 1Mohm / 30pF
- ☑ frequency response: 0Hz to 12MHz (± 3dB)
- ☑ step markers for voltage, time and frequency
- vertical resolution: 8 bit
- ☑ auto setup function
- $\ensuremath{\boxtimes}$ optically isolated from computer
- ☑ record and display of screens & data
- ☑ supply voltage: 9 10Vdc / 500mA
- ☑ dimensions: 230 x 165 x 45mm (9" x 6.5" x 1.8")
- ☑ weight: 400g (14oz)

Minimum system requirements:

- IBM compatible PC
- Windows 95, 98, ME, (Win2000 or NT possible)
- SVGA display card (min. 800x600)
- mouse
- free printer port LPT1, LPT2 or LPT3
- CD Rom player

Specifications

oscilloscope:

- timebase: 0.1µs to 100ms per division
- trigger source: CH1 or free run
- trigger level: adjustable per 1/2 division
- input sensitivity: 10mV to 3V per division
- record length: 4079 samples
- sampling frequency: 800Hz to 32MHz (Real time)
- true RMS readout (only AC component)

transient recorder:

- timescale: 20ms/div to 2000s/div
- max record time: 9.4hour/screen
- automatic storage of data
- automatic recording for more than 1 year
- · markers for time and amplitude
- zoom function

spectrum analyser:

- frequency range: 0 .. 400Hz to 16MHz
- linear or logarithmic timescale
- zoom function

1. Assembly (Skipping this can lead to troubles !)

Ok, so we have your attention. These hints will help you to make this project successful. Read them carefully.

1.1 Make sure you have the right tools:

• A good quality soldering iron (25-40W) with a small tip.



- Wipe it often on a wet sponge or cloth, to keep it clean; then apply solder to the tip, to give it a wet look. This is called 'thinning' and will protect the tip, and enables you to make good connections. When solder rolls off the tip, it needs cleaning.
- Thin raisin-core solder. Do not use any flux or grease.
- A diagonal cutter to trim excess wires. To avoid injury when cutting excess leads, hold the lead so they cannot fly towards the eyes.
- Needle nose pliers, for bending leads, or to hold components in place.
- Small blade and Phillips screwdrivers. A basic range is fine.

- Q-For some projects, a basic multi-meter is required, or might / be handy

1.2 Assembly Hints :

- \Rightarrow Make sure the skill level matches your experience, to avoid disappointments.
- \Rightarrow Follow the instructions carefully. Read and understand the entire step before you perform each operation.
- \Rightarrow Perform the assembly in the correct order as stated in this manual
- \Rightarrow Position all parts on the PCB (Printed Circuit Board) as shown on the drawings.
- \Rightarrow Values on the circuit diagram are subject to changes.
- \Rightarrow Values in this assembly guide are correct*

0.000

ο

- \Rightarrow Use the check-boxes to mark your progress.
- \Rightarrow Please read the included information on safety and customer service

* Typographical inaccuracies excluded. Always look for possible last minute manual updates, indicated as 'NOTE' on a separate leaflet.

1.3 Soldering Hints :

1- Mount the component against the PCB surface and carefully solder the leads

2- Make sure the solder joints are cone-shaped and shiny







3- Trim excess leads as close as possible to the solder joint



AXIAL COMPONENTS ARE TAPED IN THE CORRECT MOUNTING SEQUENCE !

REMOVE THEM FROM THE TAPE ONE AT A TIME !



The unit consists out of one main PCB with all the components

Tip: The pictures on the packaging can be used as a guideline. However, due to possible changes it is not 100% reliable.

Mount the components in the order described:



Construction

vellemen*

(2-2-2) (8-2-0-0) 1% (1-8-2) (1-0-1) (1-0-1) (1-0-1) (1-0-1) (4-7-1) (4-7-1) (4-7-1) (3-3) / 1W		×	04, 0.1, u1) 104, 0.1, u1)	5. 10 104, 0.1, u1) 104, 0.1, u1) 104, 0.1, u1) 104, 0.1, u1) 104, 0.1, u1) 104, 0.1, u1) 104, 0.1, u1)	$ 04, 0.1, 01\rangle$ $ 04, 0.1, 01\rangle$
	(C;	() () ()		
: 2K2 : 820R : 1K8 : 100R : 100R : 100R : 470R : 470R : 470R : 470R : 3R3	citors	° Š	: 100n : 100n : 100n : 100n : 100n	: 100n : 100n : 100n : 100n : 100n : 100n	: 100n : 100n : 100n : 100n : 100n : 100n : 100n
R44 R45 R46 R47 R48 R49 R50 R51 R52 R53	Capa		C1 C3 C6 C8 C9	C12 C13 C18 C19 C21 C24	C25 C27 C28 C29 C30 C31 C32
	3.				

□ C47 :100n (104, 0.1, u1) □ C48 :100n (104, 0.1, u1)
4. Capacitors
 □ C17 : 100p (101) □ C26 : 100p (101) □ C10 : 220p (221) □ C15 : 22p □ C16 : 22p □ C16 : 22p □ C42 : 22p □ C42 : 22p □ C4 : 2n2 /100V (222, 2200) □ C20 : 2n2 / 100V (222, 2200) □ C14 : 2n7 (272, 2700) □ C5 : 47n/250V (0.047, 473)
5. IC sockets







Construction

vellemen*



velleman*





velleman'



23. Test and adjustment

- Install the PC-Lab2000 software (see getting started manual)
- Connect the unit using a parallel cable to the computer LPT port.
- Connect a 9V/500mA power supply to the unit. (check the polarity). The LED on the front panel should lid.
- Start the PC-Lab2000 software and select K8031 hardware and the appropriate port.
- Short circuit the input using an appropriate probe or connection.
- Press the RUN button.

For all adjustment select DC input and Trigger off

Offset adjustment:

- Make sure that the Y position slider is in the centre position
- Switch always between 1V/div and 3V/div setting
- Adjust RV1 until the signal remains stable in the centre of the screen

Transient adjustment and calibration:

- Select 1V/div
- Connect the input to test point J4
- Adjust CV1 until the signal top is as flat as possible



- In the VIEW menu select "RMS value"
- Adjust RV2 until the signal is 2.5Vrms
- Select 0.3V/div
- Connect the input to test point J3
- Using the Y position slider set the signal in the centre of the screen
- Adjust CV2 until the signal top is as flat as possible

Repeat the transient adjustment and calibration at least once.

Finally use the calibrate and exit option in the File menu to complete the calibration. Mount the cover onto the enclosure (fold the screen foil).

The unit is now ready for use. Check the CD for more information.

velleman*

24. PCB IC23 J6 J2 0 J7 0 C48 C46 17 'IC22 FS1 ď b ř 0-016 БO R49 R49 R50 R51 R52 IC22 R47 010 010 010 D14 D15 R42 R43 R44 50 013 R53 **EMAN P8031** IC15 0000 00 000 00 0000000 C43 Ð (+ 3 C45 IC18 Т1 IC19 IC20 IC21 R40 IC18 O R36 O C41 O R38 O റ്റ O R37 ю C42 C40 IC16 C R35 000 C39 IC17 c VELLE (+) C36 IC16 53 IC17 (O)X1 IC11 C35 C37 IC12 IC13 IC14 IC11 IC12 3 ł IC13 IC14 0 C33 00000000 00000 C.31 IC9 IC10 R30 R28 R29 828 R31 08080 C29 C30 5 5 IC9 IC10 00000000 C27 C28 00000 R21 R23 R24 R20 319 IC6 ŏ <u>c</u>8 C7 C26 000 000 7 R17 6 O RY5 O C IC6 f ORI 40 0 C25 0 R16 C24 +^{C23} O^{RY3}O IC7 IC8 00000 0 0 RV2 IC5 0 00 C22 C21 8 8 8 D O^{RY2}O 000 R14 C20 0 ۲ ۳ R7 R13 R12 ğ IC5 00 C15 ic3 000 C16 C14 O^{RY1}O ю 02 101 0 88 C3 C12 C18 0 R11 00 \circ 5 C13 C10 IC3 CI IC4 R46 R45 ЪС C5 C6 CI õ R5 C4 00 DO OR4O 5 CV2 ß (OJ1 ſ Ъ J4 RV1 LD1 OO R2 CVI ю

25. Digital selection



26. Opto Coupler selection Ē CLK1 RCK1 ń Γ 뙯텵 3 텵 ଆଛ 뙯 ទ 1 <u>ا]</u> £[]≌ C22 11 --11-------≞[]≣ C46 <u>퇴</u>ਛ) T1 BC327 ≨∏≣ R#2 2K2 " ∄∄ IN114B PI3 P15 IN114B Ni 148 N1148 UL14B D12 IN114B P DB <u>ي</u> ____ Į 2 _____ Ĩ ,15-15 21-15 9 18-14 5-13 **76-12** 46-20 46-20 46-20 J6-22 J6-23 J6-24 J6-25

© Velleman Kit

27. Input selection



Note :

Note :



VELLEMAN KIT NV Legen Heirweg 33 9890 Gavere Belgium Europe Info ?: http://www.velleman.be Questions ?: support@velleman.be

Modifications and typographical errors reserved © Velleman Kit nv H8031IP - 2003 - ED1

