



2 4G LED RGB Controller

Main Characteristics

V3 RE RGB Remote Control

RGB Remote Option:

Working Voltage: 3Vdc (Battery CR2032)

Wireless Frequency: 2.4GHz

Working Temperature: -30°C~55°C Package Size: L150×W46×H18(mm)

Weight(G.W.): 85q

R4-3A CV Receiver

5~24Vdc Input Voltage:

3A × 4CH Max. 12A Max Current Load:

Max Output Power: 60W/144W/288W(5V/12V/24V)

Working Temperature: -30°C~55°C Package Size: L127×W35×H24(mm)

Weight(G.W.): 60a

R4-5A CV Receiver

Input Voltage: 5~24Vdc

5A × 4CH Max. 20A Max Current Load:

Max Output Power: 100W/240W/480W(5V/12V/24V)

Working Temperature: -30°C~55°C

L178×W48×H33(mm) Package Size:

Weight(G.W.): 150a


Note: Receiver is sold separately.


FC (RoHS














R4-CC CC Receiver

Input Voltage: 12~48Vdc Output Voltage: 3~46Vdc


CC 350/700/1050mA×4CH Output Current: 1.05W~48.3W×4CH Max 193.2W Output Power:


-30°C~55°C Working Temperature:


Package Size: I 178×W48×H33(mm)

Weight(G.W.): 165a

Dimensions












Operating Instruction for Remote:



Match/Clear code between remotes

Match code:



Clear code:



Press the bottom two keys of B simultaneously (about 6 seconds), the indicator light keeps on, deactivated matching successfully.

Match/Clear code between remote and receiver

Match code:

Short press the ID learning button on the receiver, the running light keeps on.

 Press any key on the remote, the running light on the receiver flicker several times, match successfully.




Receiver

Clear code


Long press "ID learning button" on receiver for 5 seconds, If the running light flicker several times, deactivate the matching successfully.

Operating Instruction for Receiver:



Wiring Diagram:









Attention:

- · Please replace the battery if the remote becomes insensitive or control distance is shortened.
- · Please take out the battery for long time unused.