


1 A POWER SUPPLY

K1823



The easy way to power your projects.

Specifications

- Great to power your projects and save money on batteries
- Suitable as an adjustable power supply for experiments
- Control DC motors, low voltage light bulbs, ...
- Short-circuit, thermal and overload protection
- Dimensions : 52x30mm (2.1" x 1.2")

Features

- ☑ Just add a suitable transformer (see table)
- ☑ Great to power your projects and save money on batteries
- ☑ Suitable as an adjustable power supply for experiments
- ☑ Control DC motors, low voltage light bulbs, ...

Specifications :

- Preset any voltage between 1.5 and 35V
- Very low ripple (80dB rejection)
- Short-circuit, thermal and overload protection
- Max input voltage : 28VAC or 40VDC
- Max dissipation : 15W (with heatsink)
- Dimensions : 52x30mm (2.1" x 1.2")

| Choose the right transformer | |
|------------------------------|--------------------|
| Max DC output voltage | Transformer rating |
| 3..5V | 9VAC / 15VA |
| 5..8V | 12VAC / 30VA |
| 8..13V | 15VAC / 30VA |
| 13..15V | 18VAC / 30VA |
| 15..18V | 22VAC / 30VA |
| 18..22V | 24VAC / 50VA |
| 22..35V | 28VAC / 50VA |




1. Assembly (Skipping this can lead to troubles !)


Ok, so we have your attention. These hints will help you to make this project successful. Read them carefully.

1.1 Make sure you have the right tools:

- A good quality soldering iron (25-40W) with a small tip.
- Wipe it often on a wet sponge or cloth, to keep it clean; then apply solder to the tip, to give it a wet look. This is called 'thinning' and will protect the tip, and enables you to make good connections. When solder rolls off the tip, it needs cleaning.
- Thin raisin-core solder. Do not use any flux or grease.
- A diagonal cutter to trim excess wires. To avoid injury when cutting excess leads, hold the lead so they cannot fly towards the eyes.
- Needle nose pliers, for bending leads, or to hold components in place.
- Small blade and Phillips screwdrivers. A basic range is fine.



For some projects, a basic multi-meter is required, or might be handy




1.2 Assembly Hints :

- ⇒ Make sure the skill level matches your experience, to avoid disappointments.
- ⇒ Follow the instructions carefully. Read and understand the entire step before you perform each operation.
- ⇒ Perform the assembly in the correct order as stated in this manual
- ⇒ Position all parts on the PCB (Printed Circuit Board) as shown on the drawings.
- ⇒ Values on the circuit diagram are subject to changes, the values in this assembly guide are correct*
- ⇒ Use the check-boxes to mark your progress.
- ⇒ Please read the included information on safety and customer service


* Typographical inaccuracies excluded. Always look for possible last minute manual updates, indicated as 'NOTE' on a separate leaflet.

1.3 Soldering Hints :

1- Mount the component against the PCB surface and carefully solder the leads




2- Make sure the solder joints are cone-shaped and shiny




3- Trim excess leads as close as possible to the solder joint






REMOVE THEM FROM THE TAPE ONE AT A TIME !

Included in
this kit



2. RESISTOR




| COLOUR | COLOUR NAME | 1ST DIGIT/ STRIPE | 2ND DIGIT/ STRIPE | 3RD DIGIT/ STRIPE | MULTIPLIER STRIPE | TOLERANCE |
|--------|-------------|-------------------|-------------------|-------------------|-------------------|-----------|
| | BLACK | 0 | 0 | 0 | x1 | 1% |
| | BROWN | 1 | 1 | 1 | x10 | |
| | RED | 2 | 2 | 2 | x100 | |
| | ORANGE | 3 | 3 | 3 | x1.000 | |
| | YELLOW | 4 | 4 | 4 | x10.000 | |
| | GREEN | 5 | 5 | 5 | x100.000 | |
| | BLUE | 6 | 6 | 6 | x1.000.000 | |


**DO NOT BLINDLY FOLLOW THE ORDER OF THE COMPONENTS ON THE TAPE.
ALWAYS CHECK THEIR VALUE ON THE PARTS LIST!**

1. Diodes. Watch the polarity !

- D1 : 1N4007
- D2 : 1N4007
- D3 : 1N4007
- D4 : 1N4007




2. Resistor



- R1 : 120 (1 - 2 - 1 - B)

3. Trim potentiometer



- RV1 : 4K7


4. Capacitors.



- C1 : 0,1 μ F, 100nF (104)


5. Terminal blocks

- SK1
- SK2




6. Electrolytic Capacitor. Watch the polarity !

- C2 : 1 μ F
- C3 : 10 μ F



7. Voltage regulator


- VR1 : LM317



It has not to be cooled if used for small powers.

8. Electrolytic Capacitor. Watch the polarity !

- C4 : 2200 μ F



9. Connection example





Fig. 1.0

Execute the connection as depicted in the figure. Connect the alternating voltage of a transformer with the 'AC IN' connections. Connect the output voltage with the '+' and '-' connections. Set the desired output voltage with trimmer RV1. Mount VR1 on a suitable heatsink for applications requiring more power.


Be sure to provide sufficient electric insulation: fit an insulator and a plastic insulation ring between the VR1 and the heatsink because the metal side of the VR1 is electrically connected with the rest of the circuit.

Replace the trimmer with a potentiometer of the same rating if you want to use the circuit as a permanently adjustable power supply.

10. PCB layout.



11. Diagram





VELLEMAN NV
Legen Heirweg 33, B-9890 GAVERE
Belgium (Europe)

